

### FX-A712M Intruder alarm system







### **Function Instruction:**

- 7 wired and 99 wireless defense zones.
- LCD screen with time clock display.
- Voice prompt for all operations.
- 3 groups of timely arm and disarm.
- Can store 6 phone numbers: When alarming, system will make alarm call to these numbers automatically.
- Can store 3 SMS numbers: When alarming, system will send alarming SMS automatically.
- 10-second automatic message recording.
- The main unit can be used as a telephone.
- Built-in artificial intelligent English message and digital voice announcer.
- Voice prompt for main unit & remote operations.
- Users can make calls by using keypad on alarm panel, just like a telephone.
- One-key-control: All the settings can be finished by keypad (out arm, home arm & remote arm).
- Arm/ disarm by SMS or call remotely and SMS alert for power failure or recovery.
- SOS, fire, gas, door, hall, window, balcony, and boundary places alarm.
- Real-time, delay, 24 hours, bypass defense zones programming function.
- Wireless coding: Easy to add additional wireless accessories.
- Remote control arm, disarm, monitor and intercom by phone.
- Built-in AAA NI-HI rechargeable battery: Make alarm when power off.

#### Wired terminal block:



# Alarm panel schematic diagram:



# **Technical parameters:**

Input Voltage	DC12V/1A
Standby Current	<55mA
Alarming Current	<450mA
Wireless Frequency	315/433MHz, PT2262/EV1527, 4.7MΩ
GSM Frequency	900/1800/1900MHz
Back-up Battery	NI-HI AAA*6 DC7.2V
Siren Volume	110dB

# Typical house configuration:

